

Mini-Mole® Sweeper



What is Mini-Mole® Sweeper?

The Mini-Mole® Sweeper is a robotic floor cleaner that automatically removes dust, fur, and other debris from under sofas, TV stands, dressers, beds, and other furniture with low ground clearance—areas that can't be easily reached manually or with other automated floor cleaners!

Mini-Mole® cleans any hard floor, including:

- ◆ Hardwood
- ◆ Laminate
- ◆ Linoleum
- ◆ Tile (ceramic, marble, etc.)

What can Mini-Mole® Sweeper do for me?

- ◆ Mini-Mole® does the cleaning for you
- ◆ Mini-Mole® gets under virtually all household furniture
- ◆ Mini-Mole® includes a rechargeable battery & a charger
- ◆ Mini-Mole® is virtually maintenance free
- ◆ Mini-Mole® is simple to use!

How do I use Mini-Mole® Sweeper?

1. Place Mini-Mole® on the floor with cleaning pad attached
2. Press the "Power" button
3. Mini-Mole® goes to work—powering down automatically when finished
4. Drop disposable cleaning pad in the trash (or clean washable cleaning pad for the next job)



Mini-Mole LLC
11 Summer Street
Danvers, MA 01923

sales@minimole.com
(978) 853-3846

